

## FIBER OPTIC SPRAY WITH STEM BASE

model 41381

### INSTRUCTIONS

Please read all instructions carefully before use. Save these instructions.

#### CAUTION:

THIS FIBER OPTIC SPRAY WITH STEM BASE IS NOT A TOY. KEEP OUT OF CHILDREN'S REACH. ONLY USE THE ADAPTER PROVIDED WITH THIS PRODUCT.

#### ADAPTER RATING:

**INPUT:** 120VAC, 60Hz

**OUTPUT:** 4.5VDC, 150mA

**FOR INDOOR USE ONLY**

#### ASSEMBLY:

1. Place the base on a level, flat surface.
2. Attach the threaded end of one stem segment into the base. You can increase the length of the stem by connecting one or two additional stem segments (*included*) before attaching socket.
3. Attach the socket to the stem segment. Be careful not to overtighten.
4. Insert the fiber optic bundle into the top of the socket.
5. The clear plastic c-clips (*included*) can be used to neatly attach the loose cord along the length of the stem.

#### OPERATION:

1. Plug the adapter plug into the cord jack.
2. Plug the adapter into wall outlet.
3. Use the three position switch, located on the fiber optic socket, to switch the unit on/off and to change functions. Move the switch to the middle position and the fiber optic bundle will illuminate and change colors. Move the switch to the far right and the fiber optic bundle will be continuously illuminated in a multicolored pattern. The far left position will switch the unit off.
4. Unplug adapter when not in use.

Note: This product uses long lasting LEDs that are not replaceable.

